

# Multi-Channel Bit Error Rate Test

Total Info Summary	All Sync Status	Sync Ch Count	Error Ch Count	Logic Error Count	Test Start	Test Duration
All channels ->	All SYNC	48	0	0	18:06:05	00:00:34

Right click to insert errors or resize columns

Dev	TS	SCh	Average Bit Error Rate	Current Bit Error Rate	Error Status	SyncLoss Count	Error Count	Error Free Seconds	Error Seconds	SyncLoss Seconds	Severely Err Seconds	Available Seconds	Unavailable Seconds
1	0		0	0	SYNC	0	0	34	0	0	0	34	0
1	1		0	0	SYNC	0	0	34	0	0	0	34	0
1	2		0	0	SYNC	0	0	34	0	0	0	34	0
1	3		0	0	SYNC	0	0	34	0	0	0	34	0
1	4		0	0	SYNC	0	0	34	0	0	0	34	0
1	5		0	0	SYNC	0	0	34	0	0	0	34	0
1	6		0	0	SYNC	0	0	34	0	0	0	34	0
1	7		0	0	SYNC	0	0	34	0	0	0	34	0
1	8		0	0	SYNC	0	0	34	0	0	0	34	0
1	9		0	0	SYNC	0	0	34	0	0	0	34	0
1	10		0	0	SYNC	0	0	34	0	0	0	34	0
1	11		0	0	SYNC	0	0	34	0	0	0	34	0
1	12		0	0	SYNC	0	0	34	0	0	0	34	0
1	13		0	0	SYNC	0	0	34	0	0	0	34	0
1	14		0	0	SYNC	0	0	34	0	0	0	34	0
1	15		0	0	SYNC	0	0	34	0	0	0	34	0
1	16		0	0	SYNC	0	0	34	0	0	0	34	0
1	17		0	0	SYNC	0	0	34	0	0	0	34	0
1	18		0	0	SYNC	0	0	34	0	0	0	34	0
1	19		0	0	SYNC	0	0	34	0	0	0	34	0

Rx, Tx, or Both: Rx & Tx | Insert Error | Pattern: QRSS | Tx Underrun Count: 0 | Configuration: [Save] [Load] | Bit Shift Subchan. [ ] User Pattern | [Exit]

[Time Slots] [Start] [Stop] [User File] [Data From File] [Reset] [Log]

## Overview

Multi-Channel Bit Error Rate Testing (MCBERT) measures correctness of data transmitted and received on T1/E1 lines/timeslots with stored data in a reference file. The application can work in real-time with data simultaneously being transmitted and received on T1/E1 lines/timeslots, or off-line with data stored in a file. The on-line T1/E1 testing can be done on full or fractional T1/E1.

The following independent streams can be compared to a pattern file.

- A Hyperchannel per T1/E1 (Nx64k timeslots, where N = 1...24 T1, 1...31 E1) line/trunk
- Multiple 64k (or 56k) channels
- Multiple subchannels Nx8K (8k, 16k...56k). For example, for T1 it could be up to 24x8 separate 8K subchannels (eight sub-channels per timeslot)

For more details, refer to [Multi-Channel Bit Error Rate Test](#) webpage.

## Functional Features

The visual interface of this application consists of the following controls:

- **Rx, Tx, or Both:** Provides options to select Rx only mode to receive the data, Tx only mode to transmit the selected BER pattern (or a pattern file), or Tx Rx mode to send and receive the data
- **Time Slots:** Allows user to select independent stream timeslots, or hyper channels, or subchannels to be tested
- **Insert Error:** Allows user to insert errors while transmitting the selected BER pattern or a file
- **Pattern File:** User can choose any type of file to be used as the reference file. The chosen file is used for either online or offline testing
- **Data from File:** For Offline analysis, user can select any type of captured file to be compared against the reference file
- **Log:** Records the comparison of Expected and Received data to a file
- **Bit Shift Synchronization:** Allows to achieve proper synchronization with smaller file sizes on sub channels



**GL Communications Inc.**

818 West Diamond Avenue - Third Floor, Gaithersburg, MD 20878, U.S.A

(Web) [www.gl.com](http://www.gl.com) - (V) +1-301-670-4784 (F) +1-301-670-9187 - (E-Mail) [info@gl.com](mailto:info@gl.com)

## Real-time and Offline Analysis

In real-time analysis, a pattern file is selected for comparing the data. The entire pattern file is read into a circular memory buffer. In online analysis this buffer is subsequently used to compare with the input stream from T1/E1 line(s) or input file. Multiple input streams are always compared to the same patterns.

Mode of received data (64kbps, n x 64kbps or n x 8kbps) is selected depending upon timeslot specification. With the start of the MCBERT, the application provides all the statistics.

In case of Offline analysis, selection of data file will be compared with the selected reference file to provide the statistics.

**Port, Timeslot and Subchannel Selection**

PORT ACTIONS	Port \ TS	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
✓ ✗ Ⓢ Ⓟ	1		1	2	3	4																			
✓ ✗ Ⓢ Ⓟ	2		1	2	3	4																			

  

**Data Transmission Rate**

Channels and Hyperchannels

☒ 64 kbps

☐ 56 kbps

☐ n x 64 kbps (hyperchannel)

**Subchannels 8-56 kbps**

☐ 8

☐ 16

☐ 24

☐ 32

☐ 40

☐ 48

☐ 56

8k Subchannels

1 2 3 4 5 6 7 8

All

None

  

**Multiple Port Selections**

Paste operations apply to the clipboard contents created by clicking on a row "C" (copy) button for the port which timeslot selection is served as the source for paste.

Select All

Clear All

Paste All

Paste Clipboard to Port List

Paste List

Apply Cancel

Card / Timeslot / Subchannel Selection

## Selecting Streams on T1/E1 Lines

The following selections can be made:

- Channels 1-24 for T1 and 1-32 for E1 per card (multiple streams per card). Hyper channel selection possible.
- Sub channels Up to 8x24/32- 8K sub channels (one or more bits per timeslot can represent a separate stream, for example, 56k is using 7 bits per timeslot. Multiple streams per timeslot and multiple timeslots per card can be used.

**Note:** When multiple timeslots are selected, selection of different data rate transmission is possible. When 64k radio button is selected, it means N separate streams of single timeslot each.

## Synchronization Algorithm and States

MCBERT can be in one of the following three states:

### NoSync

Initially MCBERT will be in NoSync state where it stays till the continuous bytes match is found between five consecutive input bytes and five consecutive pattern bytes.

### PreSync

After continuous match is found MCBERT state changes in PreSync till sufficient number of bytes are matched, so that error rate becomes below  $10^{-2}$ .

### Sync

After sufficient number of consecutive input bytes match, MCBERT enters Sync state. Any errors in PreSync or Sync state exceeding the error rate more than  $10^{-2}$  cause transition into NoSync state.

The screenshot shows the 'Bit Error Rate Test' window. At the top, a summary table displays overall test statistics. Below this is a large data table with 15 columns: Dev, TS, SCh, Average Bit Error Rate, Current Bit Error Rate, Error Status, SyncLoss Count, Error Count, Error Free Seconds, Error Seconds, SyncLoss Seconds, Severely Err Seconds, Available Seconds, and Unavailable Seconds. The table lists data for 19 channels (Dev 1 to 19). Channel 8 is highlighted in blue. At the bottom, there are control panels for 'Rx, Tx, or Both' (set to Rx & Tx), 'Pattern' (set to QRSS), and 'Tx Underrun Count' (set to 0). Buttons for 'Insert Error', 'Start', 'Stop', 'User File', 'Data From File', 'Reset', 'Log', 'Configuration' (Save, Load), 'Bit Shift Subchan.' (User Pattern), and 'Exit' are also present.

Total Info Summary	All Sync Status	Sync Ch Count	Error Ch Count	Logic Error Count	Test Start	Test Duration
All channels ->	All SYNC	48	0	0	18:06:05	00:00:34

Right click to insert errors or resize columns

Dev	TS	SCh	Average Bit Error Rate	Current Bit Error Rate	Error Status	SyncLoss Count	Error Count	Error Free Seconds	Error Seconds	SyncLoss Seconds	Severely Err Seconds	Available Seconds	Unavailable Seconds
1	0		0	0	SYNC	0	0	34	0	0	0	34	0
1	1		0	0	SYNC	0	0	34	0	0	0	34	0
1	2		0	0	SYNC	0	0	34	0	0	0	34	0
1	3		0	0	SYNC	0	0	34	0	0	0	34	0
1	4		0	0	SYNC	0	0	34	0	0	0	34	0
1	5		0	0	SYNC	0	0	34	0	0	0	34	0
1	6		0	0	SYNC	0	0	34	0	0	0	34	0
1	7		0	0	SYNC	0	0	34	0	0	0	34	0
1	8		0	0	SYNC	0	0	34	0	0	0	34	0
1	9		0	0	SYNC	0	0	34	0	0	0	34	0
1	10		0	0	SYNC	0	0	34	0	0	0	34	0
1	11		0	0	SYNC	0	0	34	0	0	0	34	0
1	12		0	0	SYNC	0	0	34	0	0	0	34	0
1	13		0	0	SYNC	0	0	34	0	0	0	34	0
1	14		0	0	SYNC	0	0	34	0	0	0	34	0
1	15		0	0	SYNC	0	0	34	0	0	0	34	0
1	16		0	0	SYNC	0	0	34	0	0	0	34	0
1	17		0	0	SYNC	0	0	34	0	0	0	34	0
1	18		0	0	SYNC	0	0	34	0	0	0	34	0
1	19		0	0	SYNC	0	0	34	0	0	0	34	0

Rx, Tx, or Both: Rx & Tx | Pattern: QRSS | Tx Underrun Count: 0

Buttons: Time Slots, Start, Stop, User File, Data From File, Reset, Log, Configuration (Save, Load), Bit Shift Subchan. (User Pattern), Exit

Multi-channel Bit Error Rate Test

## Buyer's Guide

Item No	Product Description
<a href="#">XX018</a>	Multi-Channel BERT Software

Item No	Related Software
<a href="#">XX670</a>	w/ Multi-Channel BER Testing
<a href="#">XX610</a>	w/ Transmit and Receive File Capability
<a href="#">XX020</a>	Record/Playback File software
<a href="#">XX019</a>	Transmit / Receive File Utility Software

Item No	Related Hardware
<a href="#">PTE001</a>	tProbe™ T1 E1 Base Unit
<a href="#">FTE001</a> , <a href="#">ETE001</a>	Quad and Octal T1 E1 Analyzer Boards
<a href="#">XTE001</a>	Dual Express (PCIe) T1 E1 Boards
<a href="#">TTE001</a>	tScan16™ T1 E1 Boards

**Note:** PCs which include GL hardware/software require Intel or AMD processors for compliance.

For more details, refer to [Multi-Channel Bit Error Rate Test](#) webpage.



***GL Communications Inc.***

818 West Diamond Avenue - Third Floor, Gaithersburg, MD 20878, U.S.A  
 (Web) [www.gl.com](http://www.gl.com) - (V) +1-301-670-4784 (F) +1-301-670-9187 - (E-Mail) [info@gl.com](mailto:info@gl.com)